# B2N10H-Q20L60-2LU3-H1151
# Inclinometer




## Features

- Plastic, PC
- Zero point calibration +/- 5°
- Two analog outputs
- M12 x 1 male connector

## Wiring diagram







## Technical data

| | |
|---|---|
| Type | B2N10H-Q20L60-2LU3-H1151 |
| ID | 1534006 |
| Measuring principle | Acceleration |
| **General data** | |
| Measuring range | -10…10 ° |
| Measuring range x-axis | -10…10 ° |
| Measuring range y-axis | -10…10 ° |
| Number of measuring axes | 2 |
| Repeatability | ≤ 0.2 % of measuring range \|A - B\| |
| Linearity deviation | ≤ 1 % |
| Temperature drift | ≤ ± 0.05 %/K |
| Resolution | ≤ 0.04 ° |
| **Electrical data** | |
| Operating voltage $U_B$ | 10…30 VDC |
| Isolation test voltage | 0.5 kV |
| Short-circuit protection | yes |
| Wire break/reverse polarity protection | no/yes |
| Surge protection | -48…48 VDC [$U_{b\,max.}$] |
| Output function | 5-pin, Analog output |
| Voltage output | 0.1…4.9 V |
| Load resistance voltage output | ≥ 40 kΩ |
| Response time | 0.1 s |
| | time for the output signal to achieve 90% full scale if the angle changes from -10° to +10° |
| Current consumption | 50 mA |
| **Mechanical data** | |
| Design | Rectangular, Q20L60 |

## Functional principle

Inclination is determined by a wear-free semiconducting sensor element.










B2N10H-Q20L60-2LU3-H1151| 21-02-2025 15-58 | Technical modifications reserved

## Technical data

| | |
|---|---|
| Dimensions | 60 x 30 x 20 mm |
| Housing material | Plastic, PC |
| Electrical connection | Connector, M12 × 1 |
| **Environmental conditions** | |
| Ambient temperature | -30…+70 °C |
| Vibration resistance | 55 Hz (1 mm) |
| Shock resistance | 30 g (11 ms) |
| Protection class | IP68<br>IP69K |
| MTTF | 203 years acc. to SN 29500 (Ed. 99) 40 °C |

## Mounting instructions

Mounting instructions/Description




Teaching
The zero point can be adjusted with teach adapter TX1-Q20L60.
Teach-GND is pressed for approx. 1 s to do this. The outputs are switched to 5 V as confirmation.
Teach-GND is pressed for 6 s to reset the axis zero points. The outputs are switched to 0 V as confirmation.
Once the teach button is released, the sensor returns to normal operation.

## Accessories

| GUARD-Q20L60 | A9684 |
|---|---|

Protective housing for Q20L60 inclinometers for protecting against mechanical impact; material: Stainless steel




B2N10H-Q20L60-2LU3-H1151| 21-02-2025 15-58 | Technical modifications reserved

## Accessories

| Dimension drawing | Type | ID | |
|---|---|---|---|
|  | TX1-Q20L60 | 6967114 | Teach adapter for inductive encoders, linear position, angle, ultrasonic and capacitive sensors |

B2N10H-Q20L60-2LU3-H1151| 21-02-2025 15-58 | Technical modifications reserved